



1/4




**FIG. 1**

CALL SETUP FOR 'SIP TO FIXED-WIRE PSTN' INTERWORKING



**FIG. 2**


CALL SETUP FOR 'SIP TO MOBILE' INTERWORKING



**FIG. 3**


CALL SETUP FOR 'PSTN TO SIP' INTERWORKING

4/4



**FIG. 6**

CALL SETUP FOR 'SIP TO MOBILE' INTERWORKING WITH UMM



**FIG. 7**

CALL SETUP FOR 'PSTN TO SIP' INTERWORKING WITH UMM